



12675 Danielson Ct., 403
Poway, CA 92064
858-225-8626
Fax 858-226-1881
sales@solderlab.com
www.solderlab.com

Thank you for your solder analysis order.
Follow the instructions to insure prompt
delivery and processing.

- 1) Fill enclosed solder cup(s) completely - For best results make sure your solder pot is completely mixed, clear of dross, take sample from below surface.
- 2) Mark solder cup with identifying numbers such as alloy or machine.
- 3) Complete enclosed sample card(s), matching solder sample with card.
- 4) Place solder cup and sample card in included Blue envelope.
- 5) Peel and seal envelope.
- 6) Add postage.
- 7) Send back to SolderLab.



Have you Tried PotWatch?

You have already experienced many of the great benefits that SolderLab has to offer... with PotWatch you receive

- ✓ Regular scheduled solder health checks at the frequency and duration of your choice.
- ✓ Improved soldering yield and reduced cost of rework.
- ✓ Fast and efficient turn around of critical information for manufacturing requirements.
- ✓ ISO and J-STD-001E compliance.
- ✓ Safety in the knowledge that we have digitally archived your tests.
- ✓ Improved customer confidence in the quality of the products that you manufacture.
- 😊 **Best of All...We Remember...So you don't have to!**

POTWATCH